



INSTRUCTION MANUAL

Highclere 2lt Wall Light

WARNINGS

- This is a **Class I product and must be earthed.**
- Please read these instructions carefully before commencing any work and keep them for future reference. It is recommended that this fitting is installed by a qualified electrician.
- Install in accordance with the current IEE Wiring regulations and current Building Regulations.
- To prevent electrocution switch off at mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electrical supply without your knowledge. If you are in any doubt, please consult a qualified electrician.
- This light fitting should be connected to the lighting circuit in your home.
- If replacing an existing fitting, make a note of the connections.
- Always use the correct type and wattage bulb. Never exceed the wattage stated.
- When changing a bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.
- This product is suitable for indoor use only, on normally flammable surfaces.

SPECIFICATION

Power Source: 240V~50Hz
 Class: Class I (Earthed)
 Recommended Bulb: Max. 40W E14 Candle
 LED: 3-4W LED Candle
 Suitable for use with a dimmer: Yes (Some energy saving bulbs are not suitable for use with a dimmer switch).
 Outdoor use: No

INSTALLATION INSTRUCTIONS

Make sure you have the following items which are required to install this light fitting:

- Small electrical screwdriver, cross head screwdriver & insulation tape.
- The installation of this fitting will be much easier with the help of an assistant.

Before removing the existing fitting, **carefully note the position of each set of wires.**

Remove the fixing bracket from the wall back and attach to the wall using the screws and wall plugs provided. Take care to avoid damaging any concealed wiring and pipes. **Refer to Assembly Diagram 2.**

Having identified the household wiring from your existing light fitting, connect to the connection block inside the product as shown in **Assembly Diagram 3.**

Check that.... You have correctly identified the house wires, the connections are tight, and no loose strands have been left out of the connection block.

Attach the product to the fixing bracket, by refitting the screws into the holes in the wall back and tightening the screws to secure in place. **Refer to Assembly Diagram 4.**

Attaching the shade

The shade is packed detached from the product. To attach it, unscrew the finial (A), place the shade frame (B) over the product stem (C) and retighten to secure in place. Ensure the shade is correctly oriented in front of the lampholders (**Refer to Assembly Diagrams 5 & 6).**

Fitting the bulbs: Max. 40W E14 Candle

During use the bulb and light fitting get very hot. Always switch off at the mains and allow the bulb to cool before replacing. Always use a replacement bulb of the same type and never exceed maximum wattage. Dispose of the used bulb carefully. **Refer to Assembly Diagram 5.**

Replace fuse or circuit breaker and switch on. Your light is now ready for use. **Refer to Assembly Diagram 7.**

Care and cleaning

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish.

Safety Information

For your safety, always switch off the supply before changing lightbulbs, cleaning or removing shades.

Waste electrical products should not be disposed of with household waste. Separate disposal facilities exist, for nearest facilities see www.recycle-more.co.uk or in-store for details.